T-One Get Started



Insert two 1.5V AA batteries
Warning: **the battery MINUS always goes to the spring**

1

Scan the QR code to connect **T_One_AP**

If you are unable to scan the QR code, open the Wi-Fi connection setting on your device (laptop or mobile) and choose SSID: **T_One_AP**
Enter the password:
opcnet2201 and click to connect.

2

The page for setup connection with your Wi-Fi router will open automatically with a small delay.
Note: some phones may display “Sign-in to Wi-Fi network” – click the Sign-in to establish connection



When the page is open, in the drop-down list, choose the SSID of your Wi-Fi connection, write your Wi-Fi password and click Submit.
The device will reboot to apply the data.
Note1: Refresh your browser if the page is incomplete or if your Wi-Fi router is not listed.
Note2: 5GHz is not supported. You must choose to connect the 2.4GHz
Note3: You should lose the T_One_AP connection when the device starts up (reboot).

3

After restart T_One_AP will no longer be available.
The page below will open.



You need to wait for your device to switch the connection back from T_One_APP to your router)
If it did not transfer the connection, connect your device to your router before pressing the "Continue Now" button.

4

If you made a mistake, press and hold the **Factory Default** button for 6 to 10 seconds to reset the device. You should repeat the procedure.
When you press the "Continue Now" button, the next page will open.



Fill in all the fields and click on "Create account"
Note: **First two fields should be filled in automatically - do not overwrite them**

5

The login page is located at:
https://t-one.opcnet.com

Enter your email and password you entered during creation (page 5) – click the Login button.
If you made a mistake somewhere and you nees support, please go to https://opcnet.com/support
We usually respond withing 24 hours.

6